

Section 056000

Architectural Metal Column Covers

Part 1 - General

1.01 Description of work

A. Furnish all material necessary for a complete installation of the interior and exterior column covers. Column covers to be selfaligning, positive interlock, without exposed fasteners or supports.

1.02 Submittals

A. Submit complete shop drawings detailing quantities, sizes, finish, configurations, and column attachment methods.

B. Submit product literature, specifications, information, and installation instructions.

1.03 Quality Assurance

A. Manufacturer to have a minimum of ten years experience in the manufacturing of column covers.

B. Manufacturer to inspect all aspects of the product to ensure that specifications have been met, and that they comply with approved shop drawings.

C. Manufacturer shall issue a one year limited warranty ensuring product against defects in workmanship and materials.

Part 2 - Products

2.01 Acceptable Manufacturers (or equal)

Pittcon Industries Pittcon Industries
6409 Rhode Island Ave. 3330 W. Flower Street
Riverdale, MD 20737 Phoenix, Arizona 85017

2.02 Materials

A. Column covers shall be roll-formed from (Specified Material) with (Specified Finish) to match architects sample.

- B. All fasteners are to be concealed.
- C. All support structures to be supplied by column cover manufacturer.
- D. All column covers are to be shipped with protective material on all exposed surfaces.

2.03 Fabrication

- A. Column covers shall be roll-formed to specific dimensions and tolerances, and accurately formed to radii shown on drawings.
- B. Column covers shall be fabricated in two vertically divided sections attached with a demountable interlock joint.
- C. Column covers shall be fabricated in single length heights of 16' where required, with the addition of stacking joints to allow for heights above 16'.

Part 3 - Execution

3.01 Inspection & Installation

- A. Contractor to inspect column covers upon receipt to ensure that no damage has occurred during shipment.
- B. Column cover to be correctly oriented and installed in accordance with manufacturer's shop drawings and installation instructions to ensure proper installation.
- C. Column cover to be erected plumb and level.

3.02 Cleaning & Protection

- A. Contractor to remove protective material supplied by column cover manufacturer.
- B. Contractor to clean all visible surfaces after installation.
- C. Contractor to protect column covers from damage by other trades